after they have seasoned sufficiently so that they can be handled without breaking or marring corners or faces.

Door Sills:- Where shown, concrete sills are to be cast in place, reinforced where necessary, and surfaced with metallic hardener, as specified for the laboratory work room floor; pitched and rabitted to keep out rain and light. Poured integral with floors.

Stairs:- Construct reinforced concrete stairs where shown and detailed on drawing.